


Parts online

Spare parts list



Contents


Spare parts list

Frame and hoods	1
Ground plate installation	3
Engine installation	5
Eccentric element	8
Engine	12
Fuel tank Hatz 1D81	16
Centrifugal clutch	19
Hydraulic system	21
Electric equipment	24
Throttle control, EPA version	27
Handle	29
Labels	31

Kits

One year service kit	33
Shock absorber repair kit	35
Eccentric element repair kit	37
Forward and reverse piston repair kit	39
Extension plate kit 2 x 75 mm (2 x 2.95 in.)	41
Extension plate kit 2 x 150 mm (2 x 5.90 in.)	43
Slanted extension plate kit 2 x 150 mm (2 x 5.90 in.)	45
Hour meter kit	47
Compaction Indicator Kit	49


Spare parts list Frame and hoods



Refer to the Parts Online web page for most up-to-date information. The printed information might be outdated.

Item	Part No.	Name	Qty	L
1	0211117303	Screw	8	
2	3382015367	Latch	2	
3	-	Hatch	1	
4	-	Lock	1	
5	4700397477	Front hood	1	
6	4700904650	Button head socket screw, M6x12	14	
7	4700904655	Washer, 6 x 18 x 2 mm, 0.24 x 0.71 x 0.08 in. 300 HV	14	
8	4700381882	Hinge	2	
9	4700904649	Screw	8	
10	3382014887	Safety frame	1	
11	3382015298	Lock plate	2	
12	0301231500	Washer	4	
13	0291110600	Locknut M4	4	
14	3382014898	Rear hood	1	
15	3382014889	Crossbeam	1	
16	0261109210	Nut	4	
17	0301235800	Plain washer(A) 13 x 24 x 2.5	8	
18	0211196541	Unbrako screw	4	
19	3382014886	Engine plate	1	
20	0147300074	Screw, M8 x 25 mm 8.8 A2K	4	

Spare parts list Ground plate installation




Refer to the Parts Online web page for most up-to-date information. The printed information might be outdated.

Item	Part No.	Name	Qty	L
1	3382014895	Cover	2	
2	0147140203	Hex. head screw M12 x 35	4	
3	4700904213	Steel Plain Washer	4	
4	3382012668	Engine plate	1	
5	0211196344	Hexagon socket head cap screw	10	
6	3382010021	Strap	2	
7	-	Screw M6 x 20 mm 8.8 A2K	2	
8	0147139803	Hex. head screw	2	
9	0303115900	Washer, 13x36x6 mm, 0.51x1.42x0.24 ". 300HV	4	
10	3382012993	Cover	2	
11	0147135903	Hex. head screw M10 x 16	18	
12	0300027417	Flat washer	18	
13	3382012854	Cover	2	
14	3382014568	Shock absorber	4	
15	0266211400	Hexagon nut M16	8	
16	0301237800	Flat washer	8	
17	3382014282	Rubber stop	4	
18	4700900486	Screw	4	
19	4700928441	Washer, 21 x 45 mm	4	
20	3382014937	Extension plate, 150 mm	2	
22	3382014938	Extension plate, 75 mm	2	
23	4700903290	Steel plain washer 21x36x6	8	
24	0147155103	Screw DIN933	8	
25	3382012989	Frame	1	
26	0663210617	O-ring	2	

Refer to the Parts Online web page for most up-to-date information. The printed information might be outdated.

Spare parts list Engine installation



Refer to the Parts Online web page for most up-to-date information. The printed information might be outdated.

Item	Part No.	Name	Qty	L
1	0211195735	Screw	2	
2	4700904213	Steel Plain Washer	2	
3	3382012838	Heat protection	1	
4	3382012819	Sound insulation	1	
5	3382012817	Sound insulation	1	
6	4700373476	Insulating washer	8	
7	3382012825	Exhaust pipe	1	
8	4700928849	Nut	4	
9	4700904703	Plain washer 13x24x4 mm	4	
10	4700394700	Stud	4	
11	4700281228	Bracket	1	
12	4700281194	Engine shaft	1	
13	4700350036	Key	1	
14	4700904556	Steel plain washer 8,4x16x3,0	4	
15	0147132603	Hex. head screw m8 x 30	4	
16	4700386316	Inner cover	1	
17	0147136003	Screw cap	6	
18	4812070288	Centrifugal clutch, complete	1	
19	4700904213	Steel Plain Washer	1	
20	0211132303	Screw	6	
21	0301233500	Plain washer(A) 8.4 x 16 x 1.6	8	
23	3382014242	Cover	1	
24	3382014306	Insulation	1	
25	4700373476	Insulating washer	7	
26	3382014951	V-belt	2	
27	3382014900	Cover, complete	1	
28	-	Plate	1	
29	4812060278	Captive screw M8x25, (.98".)	5	
30	0301233500	Plain washer(A) 8.4 x 16 x 1.6	5	
40	3382014892	V-belt cover	1	
41	4700281116	Clip	2	
42	4700281115	Screw	2	
43	4700281852	Oil drain, complete	1	
44	-	Connection	1	
45	4700244059	Hose	1	


Refer to the Parts Online web page for most up-to-date information. The printed information might be outdated.

Item	Part No.	Name	Qty	L
46	3382011018	Bellow	1	
47	3382011017	Bracket	1	
48	0211132203	Head screw	11	
50	3382040454	Bracket	1	
51	0147195877	Hexagon head screw	1	
52	0266211100	Nut hexagon	1	
53	4700378060	Belt tightener, complete	1	
54	4700150012	Retaining ring for shaft	1	
55	4700111180	Ball bearing	2	
56	4700151019	Retaining ring	2	
57	4700380517	V-belt pulley	1	
58	4700378061	Shaft	1	
59	0303115900	Washer, 13x36x6 mm, 0.51x1.42x0.24 ". 300HV	1	
60	0147140003	Hex. head screw M12 x 25	1	
61	0211132503	Hex. sock. screw	2	
62	4700281183	Crank holder	1	
63	4700904649	Screw	2	
64	3382012790	Bracket	1	
65	3382014348	Engine, complete, Hatz 1D81Z electric start,	1	
66	-	Engine, complete	1	
67	0211124403	Hex.socket cap screw	1	
68	3382015414	Belt guidance	1	
69	0147137703	Hex. head screw	1	
70	3382015413	Washer	1	
71	3382015470	Bearing	2	
72	3382015412	Belt pulley	1	
73	3382015440	Shaft	1	

Refer to the Parts Online web page for most up-to-date information. The printed information might be outdated.

This page intentionally left blank

Spare parts list Eccentric element



Refer to the Parts Online web page for most up-to-date information. The printed information might be outdated.


Item	Part No.	Name	Qty	L
1	3382012606	Eccentric housing	1	
2	3382012040	Hydraulic cylinder	1	
3	0211125000	Hex socket screw	12	
4	4812070043	Piston	1	
5	0570704157	Elbow 90 orfs	1	
6	0108132400	Spring pin, Ø6 x 20 mm DIN 1481	1	
7	3382014188	Sealing	1	
8	3382013002	Piston rod	1	
9	0335111400	Circlip	1	
10	3382014140	Ball bearing	2	
11	4700151043	Retaning ring for hole 28	1	
12	3382013003	Piston	1	
13	4700381443	Screw	1	
14	0335114700	Circlip	4	
15	3382014138	Bearing	4	
17	3382015158	Reverser	1	
18	4700928796	Ball bearing	2	
19	3382014460	Pin	1	
22	0211140403	Hex. socket head capscrew	8	
23	3382012625	Eccentric weight	4	
24	3382014139	Spring	1	
25	4700280448	Stop	1	
26	0335213500	Retaining ring	1	
27	3382014463	Cover	2	
28	3382015239	Cover	1	
29	3382014176	Radial lip-type seal	1	
30	4700928795	Sleeve	1	
31	0335115100	Retaining ring for shaft	2	
32	3382012027	Gear	1	
33	4700350029	Feather key	1	
34	3382012626	Eccentric shaft	1	
35	3382014774	Key	1	
36	3382012043	Eccentric shaft	1	
37	0300027464	Flat washer	4	
38	3382015331	Belt cover, hatch	1	

Refer to the Parts Online web page for most up-to-date information. The printed information might be outdated.

Item	Part No.	Name	Qty	L
39	4700500048	Screw, M10x20 mm 8.8 A3K	1	
40	4700280432	Washer	2	
41	4700282718	V-belt pulley	1	
42	0211124700	Screw M6x20, 12.9	4	
44	3382015336	Beltcover, sealed	1	
45	0686644207	Hex. sock plug	1	
46	0196124100	Set screw	2	
47	0663210617	O-ring	2	

This page intentionally left blank

Spare parts list Engine



Refer to the Parts Online web page for most up-to-date information. The printed information might be outdated.


Item	Part No.	Name	Qty	L
2	3382015173	Engine, EPA	1	
4	3382100249	Air filter cover complete	1	
5	4700239883	Cyclone	1	
6	4700239882	Elbow	1	
7	4700937017	Nut	1	
8	-	Injector part	1	
9	3382015185	Washer	2	
10	3382015186	Nut	2	
12	3382100235	Holder	1	
13	3382015187	Bracket	1	
14	3382015170	Nut, M8	2	
15	3382015169	Washer, M8	2	
16	4700239423	Air Filter	1	
17	4700239516	Housing	1	
11	4700239526	Gasket	1	
18	-	Housing	1	
19	4700239533	Washer	1	
20	4700239534	Screw	1	
21	3382100247	Gasket	1	
22	3382100238	Nozzle	1	
23	-	Injector part	1	
24	3382100237	Injector Complete	1	
25	4700950148	Injector pump, complete	1	
26	3382100241	Banjo screw	2	
27	3382100242	Gasket	4	
28	-	Pump part	1	
29	4700939616	Shim, 0.10 mm, 0.004 in.	2	
30	4700939778	Shim, 0.6 mm, 0.024 in.	1	
31	4700939777	Shim, 0.9 mm, 0.035 in.	1	
32	4700939776	Shim, 1.2 mm, 0.047 in.	1	
33	4700939779	Shim, 0.3 mm, 0.012 in.	1	
34	4700939606	Valve cover	1	
35	3382015171	Screw, M6 x 25 mm	4	
36	3382015172	Washer	4	
37	4700239333	Valve cover gasket	1	

Refer to the Parts Online web page for most up-to-date information. The printed information might be outdated.

Item	Part No.	Name	Qty	L
38	4700239426	Oil dipstick, complete	1	
39	-	Dipstick	1	
40	3382100236	O-ring	2	
41	4700935608	Oil filter cover, cpl	1	
42	-	Injector part	1	
44	3382015160	Gasket	1	
43	4700239335	O-ring	1	
46	-	Fuel filter element	1	
47	3382015189	Screw M6x12	5	
48	3382015188	Spring Washer	5	
49	4700239328	Air Filter element	1	
50	3382100648	Muffler kit	1	
51	-	Muffler	1	
52	3382100243	Gasket	1	
53	3382100244	Gasket	1	
54	-	Screw	1	
55	-	Washer	1	
56	4700945607	Charging relay	1	
57	4700935753	Gasket	1	
58	3382015190	Stud	2	
59	3382015191	Washer, M12	2	
60	3382015192	Nut, M12	2	
61	-	Safety crank handle	1	
62	4700239501	Starter	1	
63	4700239888	Hose clamp	1	
64	4700239885	Cover	1	
65	4700239508	Throttle lever	1	

This page intentionally left blank


Spare parts list Fuel tank Hatz 1D81



Refer to the Parts Online web page for most up-to-date information. The printed information might be outdated.

Item	Part No.	Name	Qty	L
1	3382100250	Fuel tank, complete	1	
2	--	Label	1	
3	4700239554	Fuel cap	1	
4	--	Fuel tank	1	
5	4700937422	Washer	12	
6	4700937423	Spacer	6	
7	4700937424	Spacer	6	
8	--	Screw, M8 x 40 mm	4	
9	4700238362	Washer	1	
10	4700937435	Plug	1	
11	4700937436	Sleeve	4	
12	4700938339	Water separator, cpl	1	
14	3382015209	Clamp	1	
15	3382015193	Adapter	1	
16	3382015194	Hose clip	1	
17	3382015195	Water separator	1	
18	3382015196	Drain screw	1	
19	4700937430	Fuel filter	1	


Spare parts list Centrifugal clutch



Refer to the Parts Online web page for most up-to-date information. The printed information might be outdated.

Item	Part No.	Name	Qty	L
1	4812070288	Centrifugal clutch, complete	1	
2	4700939359	Clutch lining	2	
3	4700939358	Weight	2	
4	4700939360	Cover	1	
5	4700939361	Screw	4	
6	4700421246	Spring	4	
7	4700939357	Hub	1	
8	4700939362	Cover	1	
9	4700939363	Lock washer	1	
10	3382100008	Ball bearing	2	
11	4700939356	Washer	1	
12	4700938725	Retaining ring	1	
13	4700938727	Nilos ring	1	
14	4700938726	Snap ring	1	
15	4700939355	V-belt pulley	1	

Spare parts list Hydraulic system



Refer to the Parts Online web page for most up-to-date information. The printed information might be outdated.


Item	Part No.	Name	Qty	L
1	0570704187	Elbow	1	
2	3390019900	Connection	1	
3	0661100025	Washer	1	
4	0211132303	Screw	3	
5	0301233500	Plain washer(A) 8.4 x 16 x 1.6	9	
6	3382014349	Hydraulic pump	1	
7	0211121803	Hexagon socket head cap screw	2	
8	0301231800	Plain washer	2	
9	3382014239	Adapter	1	
10	3382014238	Coupling	1	
11	0301232100	Plain washer(A) 6.4 x 12 x 1.6	3	
12	0266210800	Nut	1	
13	4700791415	Elbow 45, O-ring	1	
14	3382014297	Hydraulic hose	1	
15	3382014299	Hydraulic hose	1	
16	4700376677	Hydraulic oil tank, complete	1	
17	4700904960	Screw, K50 x 12 mm Type KX-PT	2	
18	4700381563	Holder	1	
19	4700500021	Screw, M8x25 mm 8.8 A2K	1	
20	4700904229	Washer, 8.4x 6x1.5 mm 300HV	1	
21	4700381385	Cover with oil dipstick	1	
22	4700381566	Air filter	1	
23	4700160110	O-ring	1	
24	-	Oil tank	1	
25	0211136303	Hex socket screw	4	
26	0300027438	Washer	4	
27	3382014893	Bracket	2	
28	0211132203	Head screw	4	
29	0570702539	Connection	1	
30	0570710005	Hose connection	1	
31	4700313108	Hose clamp	1	
32	3382012895	Hydraulic hose	1	
33	4700383458	Hose holder	1	
34	0211133203	Hex.sock screw	1	
35	3382010182	Bracket	1	

Refer to the Parts Online web page for most up-to-date information. The printed information might be outdated.

Item	Part No.	Name	Qty	L
36	4700500079	Screw M6-1x50 8,8	8	
37	4700280534	Rubber block	3	
38	3382012865	Hose holder	1	
39	0211125103	Hex sock. screw	2	
40	3382012845	Hydraulic hose	1	
41	4812070025	Control lever	1	
42	0211132503	Hex. sock. screw	1	
43	3382014298	Hydraulic valve, complete	1	
44	3382100271	Rubber cover	1	
45	3382100270	Lever	1	
46	3382100269	Pin	1	
47	3382100272	Screw	2	
48	3382100273	Washer	2	
49	3382100268	Housing	1	
50	-	Valve body	1	
51	3382100288	Measuring nipple	1	
52	0333050012	Spherical spring washer	2	
53	0291112816	Lock nut, M8	2	
54	0570704136	Connector	3	
55	3382010182	Bracket	2	
56	0261109981	Nut	2	
57	0346100024	Clamp	1	
58	4700313003	Hose clamp	1	
59	3382014346	Elbow	1	
61	3382014347	Hose coupling	1	
62	4700160328	O-ring	1	
63	0147133003	Screw	1	

This page intentionally left blank

Spare parts list Electric equipment




Refer to the Parts Online web page for most up-to-date information. The printed information might be outdated.

Item	Part No.	Name	Qty	L
1	4700378223	Cover	1	
2	4700238158	Ignition switch	1	
3	4700904428	Cover, ignition	1	
4	4700238236	Ignition key	1	
5	4700791058	Diode lamp	2	
6	4700385599	Buzzer	1	
7	3382014888	Cover	1	
8	4700903658	Screw M5x10	2	
9	4700928927	Lock nut	2	
10	-	Hour meter	1	A
11	4700378225	Cable harness	1	
12	4700500019	Hexagon screw	7	
13	4700904229	Washer, 8.4x 6x1.5 mm 300HV	7	
14	4700282727	Cable harness	1	
15	-	Nut	1	
16	-	Seal washer	1	
17	3382014678	Battery cable (+)	1	
18	0147136403	Screw hexagon	1	
19	0300013022	Plain washer	1	
20	4700281202	Battery cable (-)	1	
21	3382012765	Holder	1	
22	4700379062	Insulation	1	
23	4700394643	Battery	1	
24	3382014332	Insulation	2	
25	3382014333	Insulation	2	
26	3382012839	Insulation	1	
27	0211124303	Screw M6x10 ISO 4762	2	
28	0301232100	Plain washer(A) 6.4 x 12 x 1.6	2	
29	0346100203	Clamp	2	
30	3382012763	Battery holder	1	
31	0147132203	Hex. head screw M8 x 16	4	
32	0301233500	Plain washer(A) 8.4 x 16 x 1.6	4	
33	3382014603	Spacer sleeve	4	

Refer to the Parts Online web page for most up-to-date information. The printed information might be outdated.


Spare parts list Throttle control, EPA version



Refer to the Parts Online web page for most up-to-date information. The printed information might be outdated.

Item	Part No.	Name	Qty	L
1	3382012121	Throttle control	1	A
2	-	Throttle handle	1	
3	3382100297	Cable	1	
6	4700904747	Screw	4	
7	4700281228	Bracket	1	
10	0301232100	Plain washer(A) 6.4 x 12 x 1.6	4	
11	0211124703	Hex. head screw	4	
12	4700281236	Nipple	1	
13	4700921065	Clamp	4	
14	4700960727	Clamp	1	
15	0211132203	Head screw	1	
16	0301233500	Plain washer(A) 8.4 x 16 x 1.6	1	


Spare parts list Handle



Refer to the Parts Online web page for most up-to-date information. The printed information might be outdated.

Item	Part No.	Name	Qty	L
1	3382012558	Handle	1	
2	3382010490	Shock absorber	4	
3	4700378222	Cover	1	
4	4700500019	Hexagon screw	8	
5	4700904229	Washer, 8.4x 6x1.5 mm 300HV	8	
6	4700500043	Screw M10x16	9	
7	0300027438	Washer	9	
8	4700281382	Ball knob M12, D= 50mm	1	
9	4700581012	Nut	1	
10	0300027438	Washer	2	
11	4700282724	Hook	1	
12	0108123600	Spirol pin	2	
13	4700281431	Shock absorber	1	
14	3382012557	Handle bracket	1	
15	4700281804	Rubber stop	1	
16	4700581013	Nut, M12	2	
17	3382010495	Bushing	2	
18	0147140303	Hex. head screw M12 x 40	4	
19	4700904703	Plain washer 13x24x4 mm	8	
20	3382010496	Clamp	2	
21	3382010493	Retainer, right	1	
22	3382010491	Stud	1	
23	3382010492	Shock absorber	1	
24	3382010494	Retainer, left	1	
25	4700570006	Hex. nut	1	
26	0291112822	Locknut	4	
27	4700926911	Rubber strip	1	
28	4700902379	Edge trim	1	
29	3315019508	Lockwasher	12	


Spare parts list Labels



Refer to the Parts Online web page for most up-to-date information. The printed information might be outdated.


Item	Part No.	Name	Qty	L
1	8915002520	Label, electric engine start	1	
2	8915002523	Safety label, lock handle	1	
3	8915002526	Safety label, rotating V-belts	1	
4	3382012659	APT logo	2	
5	8915300266	Product label "RP 504"	2	
6	8915002529	Safety label, read instruction manual	1	
7	-	Label, noise level	1	
8	8915002521	Label, throttle control non EPA	1	
9	8915002530	Label, throttle control EPA	1	
10	8915002519	Label, charging, hour meter and engine oil pressure	1	
11	8915002528	label, lifting point	1	
12	8915002387	Safety label, read instructions, ear protection and safety boots	1	
13	-	Data plate (Not available separately)	1	
14	-	Screw M6 x 20 mm 8.8 A2K	4	
15	8915002525	Label, operator panel	1	
16	8915002527	Label, manual start	1	
17	8915002427	Label, hydraulic oil level	1	
18	4700904601	Decal biodegradable hydraulic oil	1	
19	8915002626	Label,fuel	1	
21	8915002524	Label sound level	1	
22	3382012638	Product label "APT LOGO"	1	

Kits One year service kit



Item	Part No.	Name	Qty	L
1	3382100659	One year Service kit	1	
2	3382100611	500 Hours Service Kit / 12 Months Service Kit	1	
3	4700239326	Oil filter	1	
4	4700937873	Fuel filter	1	
5	4700239423	Air Filter	1	
6	4700381566	Air filter	1	
7	4700386312	V-belt	2	
8	3382100573	Every 250 hours / six months	1	
9	4700239326	Oil filter	1	
10	4700937873	Fuel filter	1	
11	4700239423	Air Filter	1	
12	9234001203	Cobra & compactor Impact-OIL 1L	2	

Kits Shock absorber repair kit




Item	Part No.	Name	Qty	L
-	3382100581	Shock absorber repair kit	1	
1	3382014568	Shock absorber	4	
2	0266211400	Hexagon nut M16	8	
3	0301237800	Flat washer	8	
4	3382010490	Shock absorber	4	
5	0147135903	Hex. head screw M10 x 16	8	
6	0300027438	Washer	8	
7	3382010492	Shock absorber	1	
8	0147140303	Hex. head screw M12 x 40	4	
9	4700904703	Plain washer 13x24x4 mm	8	
10	0291112822	Locknut	4	
11	4700281431	Shock absorber	1	
12	0108123600	Spirol pin	2	
13	4700581012	Nut	1	
14	0300013022	Plain washer	2	
15	0266211100	Nut hexagon	1	

Kits Eccentric element repair kit




Item	Part No.	Name	Qty	L
-	3382100582	Eccentric element repair kit	1	
1	3382014176	Radial lip-type seal	1	
2	3382014138	Bearing	4	
3	4700928796	Ball bearing	2	
4	0335213500	Retaining ring	1	
5	0211124700	Screw M6x20, 12.9	4	
6	0300027464	Flat washer	4	
7	0333520018	Lock washer	16	
8	0211125000	Hex socket screw	12	

Kits Forward and reverse piston repair kit




Item	Part No.	Name	Qty	L
-	3382100583	Forward and reverse piston repair kit	1	
1	3382014188	Sealing	1	
2	0335111400	Circlip	1	
3	3382014140	Ball bearing	2	
4	4700151043	Retaning ring for hole 28	1	
5	0108132400	Spring pin, Ø6 x 20 mm DIN 1481	1	
6	0211124700	Screw M6x20, 12.9	4	
7	0333520018	Lock washer	4	

Kits Extension plate kit 2 x 75 mm (2 x 2.95 in.)




Item	Part No.	Name	Qty	L
1	3382014950	Extension plate kit 2 x 75 mm (2 x 2.95 in.)	1	
2	-	Extension plate, 75 mm, 2.95 in.	2	
3	-	Washer, 21 x 36 x 6 mm, 0.83 x 1.42 x 0.24 300 HV	8	
4	-	Screw, M20 x 50 mm 8.8 A9K	8	

Kits Extension plate kit 2 x 150 mm (2 x 5.90 in.)



Item	Part No.	Name	Qty	L
1	3382014952	Extension plate kit 2 x 150 mm (2 x 5.90 in.)	1	
2	-	Extension plate, 150 mm, 5.90 in.	2	
3	-	Screw, M20 x 50 mm 8.8 A9K	8	
4	-	Washer, 21 x 45 mm, 0.83 x 0.87 x 1.77 in. 300 HV	8	

Kits Slanted extension plate kit 2 x 150 mm (2 x 5.90 in.)




Item	Part No.	Name	Qty	L
1	4700382068	Slanted extension plate kit 2 x 150 mm (2 x 5.90 in.)	1	
2	-	Extension plate, 150 mm, 5.90 in., Slanted 2.5°	2	
3	-	Screw, M20 x 50 mm 8.8 A9K	8	
4	-	Washer, 21 x 45 mm, 0.83 x 0.87 x 1.77 in. 300 HV	8	

Kits Hour meter kit

NO EXPLODED VIEW
AVAILABLE
FOR THIS BOM

Item	Part No.	Name	Qty	L
1	4700376948	Hour meter kit	1	
2	4700385600	Hour meter	1	
3	-	Screw, M3 x 10 mm	2	
4	-	Nut, M3	2	

Kits Compaction Indicator Kit



Refer to the Parts Online web page for most up-to-date information. The printed information might be outdated.

Item	Part No.	Name	Qty	L
-	3382100627	Compaction Indicator Kit	-	
1	3382012189	Wiring harness	1	
2	0211125003	Screw, M6x30, 8.8	4	
3	4700903658	Screw M5x10	4	
4	4700904346	Clamp	3	
5	0301232100	Plain washer(A) 6.4 x 12 x 1.6	5	
6	0211196477	Hex. sock. Screw	3	
7	0291112815	Locknut	2	
-	3382014830	Compaction Indicator Kit	-	
8	-	Measure unit	1	
9	-	Compaction meter	1	