



PARTS BREAKDOWN

2" SEMI-TRASH PUMP

MODEL: PA-WPT2B






PARTS BREAKDOWN

2" SEMI-TRASH PUMP

MODEL: PA-WPT2B

PUMP ASSEMBLY



REF #	DESCRIPTION	QTY	PART #
1	Pump Body	1	PA-P5010205
2	Plug	2	PA-P50002203
3	O-ring	2	
5	O-ring	6	PA-P50102103
6	Check Valve	1	
9	Spring Column Pin	2	
10	O-ring	1	
11	O-ring	1	
13	Mechanical Seal	1	PA-P50102100F
7	Diffuser	1	
8	Impeller	1	PA-P50102101F
12	Pump Cover	1	PA-P90850010BE
15	Strainer	1	PA-P50002014
**	Complete Pump Assembly	1	PA-P85150312F




PARTS BREAKDOWN

2" SEMI-TRASH PUMP

MODEL: PA-WPT2B

FRAME ASSEMBLY



REF #	DESCRIPTION	QTY	PART #
1	Frame	1	PA-P50102108
2	Bolt	4	PA-P50002205
3	Engine Frame Shock Absorption Seat	4	
4	Acorn Nut	4	

***CHECK WITH HONDA FOR ENGINE BREAKDOWN AND PARTS**



If you need technical assistance call:

1-800-818-1199

(8:00am - 4:30pm PST, Mon - Fri)